INDIA.....91

\*CANADA

TO CALL CANADA, DIAL 1 + AREA CODE + LOCAL NUMBER.

\*MEXICO

TO CALL MEXICO, DIAL 011 + 52 + CITY CODE+ LOCAL NUMBER.

To dial international calls:

International Access Code + Country code + Routing code

Example:

To call Frankfurt, Germany, you would do the following:

011 + 49 + 611 + (# wanted) + # sign(octothrope)

The # sign at the end is to tell Bell that you are done entering in all the needed info.

## 157.The Infinity Transmitter: by <<<Ghost Wind>>>

FROM THE BOOK BUILD YOUR OWN
LASER, PHASER, ION RAY GUN & OTHER WORKING SPACE-AGE PROJECTS
BY ROBERT IANNINI (TAB BOOKS INC.)

Description: Briefly, the Infinity Transmitter is a device which activates a microphone via a phone call. It is plugged into the phone line, and when the phone rings, it will immediately intercept the ring and broadcast into the phone any sound that is in the room. This device was originally made by Information Unlimited, and had a touch tone decoder to prevent all who did not know the code from being able to use the phone in its normal way. This version, however, will activate the microphone for anyone who calls while it is in operation.

NOTE: It is illegal to use this device to try to bug someone. It is also pretty stupid because they are fairly noticeable.

## Parts List:

Pretend that uF means micro Farad, cap = capacitor

Part	#	Description
		·
R1,4,8	3	390 k ¬ watt resistor
R2	1	5.6 M ¬ watt resistor
R3,5,6	3	6.8 k ¬ watt resistor
R7/S1	1	5 k pot/switch
R9,16	2	100 k ¬ watt resistor
R10	1	2.2 k ¬ watt resistor
R13,18	2	1 k ¬ watt resistor
R14	1	470 ohm ¬ watt resistor
R15	1	10 k ¬ watt resistor
R17	1	1 M ¬ watt resistor
C1	1	.05 uF/25 V disc cap
C2,3,5,6,7 5 1 uF 50 V electrolytic cap or tant (		1 uF 50 V electrolytic cap or tant (preferably non-polarized)
C4,11,1	2 3	.01 uF/50 V disc cap